

MyTana Folding Ramp Instructions

1. Slide plastic covers over the corners and align the holes for the screws.



2. Lock the plastic covers in place with the hardware as shown. The female threaded grommet should be facing the ramp surface.



3. Using two philip screw drivers tighten the screws securely. You're ready to go!



www.MyTana.com

746 Selby Ave • St. Paul MN, 55104
fax: 651.222.1739

1.800.328.8170

Factory Direct Customer Service
M-F 7am – 5pm CST
Competent • Polite • Clear